



NOTE:

- | | |
|--|---|
| <p>1.) SERVICE MATERIALS AND DISINFECTION REQUIREMENTS PER KCWA SPECIFICATION UNLESS CITY OR TOWN CODES REQUIRE SPECIFIC MATERIALS THAT HAVE BEEN APPROVED BY KCWA.</p> <p>2.) SERVICE LINE FROM CURB BOX TO BUILDING SHALL BE INSPECTED, TESTED AND APPROVED BY THE LOCAL PLUMBING INSPECTOR.</p> | <p>3.) ONCE DISINFECTED FOLD AND CUT SERVICE LINE TO CONNECT TO CURB STOP.</p> <p>4.) BACKFLOW AND VALVES MAY BE PLACED BELOW GRADE IF SECURE PLATE IS USED TO COVER OPEN EXCAVATION.</p> |
|--|---|

TEMPORARY SERVICE CONNECTION
FOR PRESSURE TESTING & DISINFECTION

NOT TO SCALE